



RadioRay LED Retrofit Instructions

1. Remove the four screws that secure the bezel of the light and remove the lens and reflector.
2. **Gently** lift the center and subsequently the lateral tabs on the power connector and remove it from the back of the bulb.
3. Remove the top housing of the Golight by first removing the “ears” that act as screw caps, or the handle if retrofitting a portable unit, and then remove the screw on both sides of the housing.
4. Remove the lamp housing
5. Attach the power connector to the LED unit be sure to align all three tabs to ensure a proper connection.
6. Slip the two red power wires into the p-hook so that the wires do not impede the function of the Golight.
7. Place the LED module in the lamp saddle and reassemble the Golight.



Feel free to contact us at any time with questions or comments at 800.557.0098 or at info@golight.com.