



Golight / RadioRay Receiver Replacement

Please see Golight/RadioRay Disassembly before starting step 1

1. Remove two deck plate screws and slide the plate/bulkhead assembly straight up and out.
2. Unplug the power wire and motor wires from the receiver. You will also have to pull up on the flat green antenna that runs from the top of the motor to the receiver. The antenna is attached with double stick tape.
3. Remove the screws that hold the receiver in place and pull it away from the bulkhead assembly.
4. Place the new receiver on the bulkhead. *Make sure the tab on the receiver is lined up correctly with the tab on the bulkhead assembly. Insert screws to hold new receiver in place.
5. Plug all the wires back into the receiver in their correct position. Reattach the antenna with two sided tape.
6. Pull the cords tight through the base of the light and insert the bulkhead assembly back into the light's bottom housing. Two tracks run vertically along the left and right side of the bottom housing, line-up the bulkhead assembly with these tracks up before inserting back into the light body.

NOTE: Make sure the black stopper is small end up and sitting in the track on the base of the light. The stopper needs to be lined-up to fit in the track that is on the bottom of the bulkhead assembly. (See Pictures)

7. When correctly in place, the base plate of the bulkhead assembly will fit flush with the bottom housing.
8. Insert and tighten the (2) deck plate screws. (They are the larger of the (4) screw that are left.)
9. Place the lamp housing back in its correct spot. Then put the top housing back on the light.

Please see Golight/RadioRay Reassembly

