



## ***Wired Dash Mount Remote Identification***

RE: Correctly identifying what model of hard wired dash mount remote you need:  
2020-D, 2049-D or 3020-D

Although the face side of the 2020-D and 2067-D control panels appear identical they are not interchangeable. The number 2020 or 2067 should be printed on the portion of the joy stick that protrudes from the back of the panel. If it is not easily accessed or is missing differences are listed below.

### **2020-D / Golight**

1. The on/off switch of the 2020-D is a single pole/single throw that is up for on and down for off.
2. The 2020-D has a square nine pin plug.

### **2067-D / Golight**

1. The 2067-D's on/off switch is spring loaded, can be moved either up or down to turn the light off or on and returns to center when released.
2. The 2067-D has a green circuit board with a rectangular seven pin socket.

### **3020-D / Stryker**

1. The 3020-D on/off switch is spring loaded, can be moved either up or down to turn the light off or on and returns to center when released.