



## ***General Wireless Remote Operation***

1. Mount Light per the Instruction Manual and apply power
2. Using the remote control, turn on the light by depressing the power button.
3. The 4 directional arrows on the remote control rotate your light to the desired location. Depending upon conditions, the wireless remote may be used up to 80 feet from the Light.
4. The rotation speed of the light can be controlled by depressing the tortoise or the hare button on the remote.

